

## Cable Assemblies

Model Number:

### In-Building Antenna Accessories

**ICSM**

All cable assemblies listed below are used to connect I-ceiling and MicroSphere antennas, which offer SMA-Female connectors, to various wireless system radios. Please consult your manufacturer to determine exactly what type of external RF connectors are offered on their wireless device.

### Specifications:

Model #	Part #	Plenum Rated Coax	Connector Type	Wireless System Hardware
ICSM-RT36	CAF94121	3' RG-142	SMA-Male/ RP-TNC	<ul style="list-style-type: none"> <li>▪ Cisco Aironet</li> <li>▪ Proxim Harmony</li> </ul>
ICSM-RT60	CAF94272	5' RG-142	SMA-Male/ RP-TNC	<ul style="list-style-type: none"> <li>▪ Cisco Aironet</li> <li>▪ Proxim Harmony</li> </ul>
ICSM-LURA24	CAF94306	2' RG-316	SMA-Male/ WaveLAN Plug R.A.	<ul style="list-style-type: none"> <li>▪ Agere/Avaya/Lucent Orinoco</li> <li>▪ Enterasys RoamAbout 2000</li> <li>▪ Buffalo Technologies AirStation</li> </ul>
ICSM-RB60	CAF94316	5' RG-142	SMA-Male/ RP-BNC	<ul style="list-style-type: none"> <li>▪ Symbol Spectrum24</li> <li>▪ Intel PRO/Wireless</li> </ul>
ICSM-SM60	CAF94134	5' RG-142	SMA-Male/ SMA-Male	
ICSM-NM60	CAF94152	5' RG-142	SMA-Male/ N-Male	
ICSM-NF60	CAF94226	5' RG-142	SMA-Male/ N-Female	



Pattern data files for SitePlanner are available at [www.centurion.com](http://www.centurion.com) or [www.wirelessvalley.com](http://www.wirelessvalley.com).



**ICSM-RT36**



**ICSM-RT60**



**ICSM-LURA24**



**ICSM-RB60**



**ICSM-SM60**



**ICSM-NM60**



**ICSM-NF60**

Specifications subject to change without notice.

ICSMa- 6/30/04